



## INSTALLATION

1. Adjust the slide dampers to the desired opening.
2. Remove horizontal return air cover.
3. Attach the fresh air damper to the unit in place of the return air cover.